

TUTORIAL: Clean Installation TyphoonN CyanogenMod 7 with MAGLDR

A clean installation resets your phone to a state without any personal data on it. **This means you lose your settings, applications and data.** The first installation of an Android ROM obviously is a clean installation. On subsequent installations a clean installation may help to avoid problems caused by bad data.

Prerequisites:

1. HSPL 2.08.HSPL installed
 - [HOW-TO for HD2 with 512 MB ROM](#)
 - [HOW-TO for HD2 with 1024 MB ROM \(T-Mobile US\)](#)
2. [Radio Leo 2.15.50.14](#) installed

Steps:

1. Preparation
 - a. Load battery to 100% (to avoid running out of power in case of problems)
 - b. Backup contents on your phone using tools appropriate for your system
 - c. Backup contents on your SD card (copy files to a directory on the PC)
 - d. Power off phone
 - e. Make sure your SD card is partitioned properly: It should contain exactly one FAT32 partition, re-partition if necessary (**this will erase all data on your SD card**), you might use [GParted](#) to do so
 - f. Format your SD card (**this will erase all data on your SD card**): Choose the FAT32 file system and a quick format (there is no need to write all sectors of flash RAM)
2. Erase phone memory (ROM and data) completely
 - a. Power on phone, hold <Volume down> button until the boot loader appears (a screen with red/green/blue/white rectangles)
 - b. Connect phone to PC via USB (use a direct USB link, avoid USB hubs) until "USB" appears in the white rectangle
 - c. Run [task29.exe](#) on the PC
 - d. Power off phone (remove and reinsert battery if necessary, reconnect to USB)
3. Install MAGLDR
 - a. Power on phone, hold <Volume down> button until the boot loader appears, "USB" should appear in the white rectangle
 - b. From the PC, flash [MAGLDR 1.13](#) (run ROMUpdateUtility.exe)
 - c. Power off phone (remove and reinsert battery if necessary, reconnect to USB)
4. Install CWM (ClockworkMod Recovery)
 - a. Power on phone, hold <Power> button until the MAGLDR Boot menu appears
 - b. Select option „USB Flasher“ (press <Volume down>, <Volume up> buttons to change menu option, press <Call> button to select)
 - c. From the PC, flash the ClockworkMod Recovery version posted in [OP of TyphoonN thread](#) (run DAF.exe)

5. Start CWM
 - a. Select option „AD Recovery“ (this will start CWM)
 - b. Wait until ClockworkMod Recovery menu appears
6. Use CWM to copy ROM and packages to SD card
 - a. Select option „mounts and storage“
 - b. Select option “mount USB storage” (on the PC a message requesting you to install a driver for “ADB” might appear, dismiss it)
 - c. If the SD card does not appear as a drive on your PC, unplug the phone's USB connection, then reconnect it
 - d. Copy the zip files for ROM (TyphoonN_*.zip for MAGLDR as posted in [OP of TyphoonN thread](#)) and, optionally, kernel and other packages to SD card root directory,
 - e. On the PC, use “Safely remove hardware” function to disconnect the SD card
 - f. On the phone, select “Unmount”
 - g. Press <Back> button to return to CWM main menu
7. Use CWM to install ROM and packages from SD card
 - a. Select option „install zip from sdcard“
 - b. Starting with the ROM, for each package do:
 - i. Select option „choose zip from sdcard“
 - ii. Select the package's zip file
 - c. Press <Back> button to return to CWM main menu
 - d. Select option „advanced“
 - e. Select option „Fix Permissions“
 - f. Press <Back> button to return to CWM main menu
 - g. Select option „reboot system now“